



Make the benchtop frame using 2 100mm x 1150mm pieces and 3 100m x 740mm. Drill pilot holes and screw together.



Make leg frames with 4 100mm x 775mm and 2 100mm x 1075mm (crosspieces). Screw latter 250mm up from bottom.



Attach leg frames to benchtop frame. Drill pilot holes and screw, using 2 screws per leg. Leg frames sit inside benchtop frame.



Turn frame upright. Lay 6 lengths 150mm x 740mm on the frame to make a shelf. Measure the gap and cut 7th piece to fit.



Line up shelf edges so they sit flush with the outside leg edges, then nail the seven pieces in place to secure the shelf.



Sand the rough edges. The square edges can be slightly rounded to give a smooth finish. A sanding block is the perfect tool.



Lay the 6 remaining pieces on top of the frame. Line up the edges so they overhang about 250mm on each side.



Nail in place (at each end and in the middle of the table), then tidy the edges with sandpaper. Paint or stain – or leave au naturel.



Results COMPOST

A mixture of organic ingredients ideal for improving soil structure.
40 Litre.
330219 2

\$5.10 bag 4 for \$19.40



fertiliser. 40 Litre. 139178 4

\$6.98 bag





Results
SLOW
RELEASE
FERTILISER
Keeps your garden fed for up to 3 months from one

simple application.

500g. 141822 3 \$6.49

MULTI PURPOSE SCOOP 119279 1 \$7.13





Available from Monday 1st to Tuesday 30th November 2010, while stocks last NV1444



DRAFTFCB 5760 NOV